



ARI-CARE cod. 13922

Ariete have developed and produced the **ARI-CARE** line which can be used to extend the life of your **ARI-** original XNBR elastomer fork oil seals. Made to enhance the durability, smoothness, and overall performance of your seals. ARI-CARE is made up of two products made for specific jobs. For best results, you need to make sure all mud, sand etc are removed from the forks, then follow these two easy steps:

STEP1: Stems PREPARATION

Pour just a few drops of STEP1 cleaner onto a clean cloth, then wipe evenly over the fork stems and fork seals to remove any impurities.

STEP2: PROTECTION and TREATMENT of rubber parts.

1. Place the spout of STEP2 sachet in contact with the oil seals and squeeze out a few drops onto the rubber surface, then spread evenly across the rubber part. Remove any excess with a clean cloth.
2. Repeat the above step on the fork stems.

Protector helps protect the rubber from general wear and tear caused by weather or chemicals in cleaners etc as well as preventing any surface cracking on the seals.

This product, and process creates a protective film around the seals and on the fork stems, extending the life of your seals and enables a flawless performance for a much longer period. The molecular property of this film not only protects the surface, but also helps in preventing any impurities sticking to the seals or fork stem.

It also helps lubricate your forks, meaning decreased friction between metal and rubber, improving your riding experience.



COD. 13922 made by Super Help srl – 21100 VARESE – ITALY, Ph: +39 347 4650120 – info@super-help.com www.super-help.com

STEP1: 75 ml FORK CLEANER: UFI: RP62-U0S5-3009-U152

STEP2: 25 ml CONDITIONER



STEP1 English - WARNING

Causes serious eye irritation

If medical advice is needed, have product container or label at hand.

Keep out of reach of children.

Wear protective gloves/protective clothing/eye protection/face protection.

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

If eye irritation persists: Get medical advice/attention

REGULATION (EC) N. 648/2004 LESS THAN 5% NON-IONIC SURFACTANTS.

STEP2 English - WARNING

Keep out of reach of children.